

## USE OF SOFT GOODMAN HANDLE

The soft goodman handle is mounted on the hand as seen on the picture below. One sling in the palm and the other around the wrist.



## AFTER USE MAINTENANCE

- Rinse the dive light with fresh water after use.
- Lubricate the o-rings with silicone grease if necessary.
- Disconnect the battery if the light is not used for long periods or when transporting by air.
- Inspect the o-ring for damages and dirt. Replace o-rings or clean them if necessary.
- Charge the light at least every 6 month.


## RECYCLING

This product contains electronic components and must not be disposed of with household waste. Leave the product for recycling in designated areas, such as municipal recycling centers.

## WARRANTY

Provided the product is used as intended, two years of warranty is given on the light. The warranty is valid provided that a receipt of the purchase can be presented, and includes repair or replacement of defective parts.

## APPROXIMATE BURN TIMES




## OPTIONAL ACCESSORIES

These accessories can be purchased by your local Nanight dealer.



The C3 comes with either a carbon fiber or aluminium goodman handle. The aluminium handle, you can easily adjust the size to fit your hand, and when not diving it can be folded flat. The thumb grip enables smooth control and variation of

**Aluminium Goodman Handle, NT-AGH.**



When using thick gloves or if you have large fingers, the switch extender simplifies the switch handling.

**Switch Extender, N-SE**



## Nanight C3 User Manual

Thank you for choosing a dive light from Nanight! The light is designed for diving at depths of up to 100m. We at Nanight hope your new light will give you many rewarding days and nights of diving!

## PRODUCT DESCRIPTION

- LED Type: Cree XHP70
- Battery: 14,4V Panasonic Li-Ion, 6700 mAh
- 4-step dimming
- Operating temperature: 0 – 35°C
- Depth rating: 200m
- Light output 4000 emitter lumen
- Beam Angle: 5°
- Weight: 1270 g
- Burn time: See burn time graph on page 7



## NANIGHT C3 INCLUDES

- Dive light
- Charger
- Soft goodman handle
- Carbon Fiber or Aluminium goodman handle
- Case
- Canister mount HD
- Canister velcro quick strap

## BATTERY INFORMATION

The lithium ion battery is certified for flying according to UN 38.3, and the energy content is below the allowed upper limit. As specified by the certification, the battery should not be removed from the product before or during flying. Depending on regulations between different airlines you should either fly with your lights as hand luggage or checked in luggage.

## WARNING

The battery pack in this light is of Li-Ion type. This kind of battery may explode if charged incorrectly, short circuited or damaged in any way. Charge the light outside away from flammable materials. Never charge the light in direct sunlight or in temperatures above 35°C. If the light or battery becomes hot, immediately disconnect the charger, open the light and place the light in a fire proof area outside and don't use the light again until a Nanight service center has checked the light. Never use a light that has been flooded. Regularly open the light and check for over pressure if the light is equipped with an external charging port. Replace the battery if the battery is damaged or has significantly lost capacity. Only use original Nanight battery packs with this product.



When diving in dark water, a backup dive light should always be brought. This is a bright light. Never direct the light directly into the eyes of yourself or others. When using the dive light above water, it may become hot. Be careful not to burn yourself or others. Do not disassemble the dive light while it's still wet.

## CONTACT INFORMATION

www.11bar.de

## CHARGE THE BATTERY



-  **Make sure the Charge Port is completely dry.**
- Attach the brass adaptor to the Charge Port.
- Connect the charger to the wall and plug in the DC connector to the brass adapter.
- The charger will indicate charging by a red LED. A green led will indicate completed charge.
- Disconnect the charger.
-  **Always remove the brass adapter after charging.**

## USAGE

The drop-shaped knob controls the functionality of the light. Loosening or tightening the screw can adjust knob friction.

## SWITCH THE LIGHT ON

- Turn the knob clockwise. The light will always start on step 3/4.
- If the battery level falls below 10%, the amount of light will automatically be reduced to optimize the battery performance and allow the user to terminate the dive safely.


## SWITCH THE LIGHT OFF

- Turn the knob counterclockwise until it touches the locking position, the light will go off with a delay of 2 seconds.
- Whenever outside of the water, turn the knob counterclockwise past the locking position, to ensure that the light is not accidentally switched on.

## DIM THE LIGHT


- Turn the knob counterclockwise until it touches the locking position, and back again within 2 seconds.
- Repeat the maneuver for further dimming.
- In this way, the light is dimmed gradually in four steps, and back again to the highest brightness
- The light will always start up on step 3/4.

Note that the light automatically dims down when the battery level drops below 10%.



## Battery level indication

To check the battery charge status: turn the light on and then off within 2 seconds, a number of short flashes indicate battery charge status.



Flashes	Battery Level
4	75-100%
3	50-75%
2	25-50%
1	5-25%